

E39 M5 Computer Removal Directions

1) Verify that you key will manually get you in and out of your gal or leave a window down because once the battery is disconnected the opener will not longer function

2) Disconnect the ground side of the battery

3) Remove passenger side micro filter box as follows; remove some clip in the front center, unlatch the lid, unclip the three clips at the air inlet tube that goes in-between the micro-filer box and the firewall of the car, gently lift out the box raising it from the edge closest to the motor and pull it out,

3) Remove the allen screws securing the white lid that covers the DME compartment

4) Then beginning at the plug closest to the center of the car remove one plug at a time

The first plug you press the tab in and lift up

The next three plugs all have the arms on them so you have to press the little button in and then gently slide the arm don and while doing so it will automatically release the plugs. The last plug is as the first simply press in the tab and gently lift up

4) Then slide the DME out, wrap it in an antistatic material to prepare for shipping. Any bag that computer hardware ships in will work. (harddrive, motherboard, video card)

NOTE: Please make sure and send the computer with the buildsheet together to the address listed on your invoice. We ask that you use UPS am delivery no signature required for best results. Best efforts will be made to return your computer to you on the afternoon truck if it arrives to us in the am.

Discovery Automotive
4120 Studebaker Rd.
Placerville CA 95667